



型号	额定电压 (V)	安装位置	极数	触头组成		触点布局	适用接触器
				NO	NC		
YEDF4-02				0	2		YEDCJX2s 09~65
YEDF4-11			2	1	1		
YEDF4-20				2	0		
YEDF4-04	380V	顶端		0	4		
YEDF4-13				1	3		
YEDF4-22			4	2	2		
YEDF4-31				3	1		
YEDF4-40				4	0		

适用接触器详见P163。